

BRT-12

BATTERY REPLACEMENT TOOL



Instruction Manual

Contents

INTRODUCTION	3
Safety Information	3
Product Details	3
DISPLAY AND KEYPAD	4
USER INTERFACE	5
FIRST TIME USE	6
OPTIONS MENU	7
Main Menu screen	7
REPLACING THE BATTERY	8
Example system:	8
CHANGING THE PRESET LANGUAGE	9
READING UNIT INFORMATION	10
SOFTWARE UPDATE	11
Overview:	11
Minimum requirements:	11
SPECIFICATIONS	12
Features:	12
Specifications:	12
COPYRIGHT AND WARRANTY	13
Copyright:	13
Warranty:	13

INTRODUCTION

Please read this information carefully before using your new Battery Replacement Tool

Thank you for purchasing your Battery Replacement Tool. We at Exide believe that you will have many years of successful business as a result of your investment and it is our aim to ensure that you will remain as up-to-date as possible.

Always ensure you have the latest version of software and vehicle data that is available. Follow the instructions on [Page 11](#) for [Software Update](#).

Please refer to this manual when using the tool and don't hesitate to contact your distributor if you experience any difficulty with it.

Safety Information




- Always wear eye protection when handling batteries.
- Keep batteries away from children.
- No smoking, avoid open flames or creating sparks near batteries.
- Explosion hazard. Batteries emit an explosive mixture of hydrogen and oxygen during and after charging.
- Corrosive hazard. Wear protective equipment to shield eyes, hands, and clothing

Product Details:

Modern battery management systems used in some of today's vehicles require their systems to be reconfigured each time a battery is fitted, the BRT-12 allows you to reconfigure the stored battery data on these modern vehicles.

The BRT-12 lets you enter the new battery information quickly and simply, it can also display the current battery's details.



DISPLAY AND KEYPAD



USER INTERFACE



Navigation buttons

- The arrow keys are used to navigate through the menus.
- The OK button is used to confirm a selection.
- The ESC button is used to go back to the previous screen.



The mini USB connector is used to connect to a PC to allow you to update the tool with additional software.





The J1962 connector needs to be connected to the vehicles OBD socket in order to get power and make communications to the particular vehicle.

This is fitted as standard to any petrol vehicle from 2000 and any diesel vehicle from 2004



FIRST TIME USE

When the Battery Replacement Tool is first powered you have to select the language you want to use the tool in. This screen only appears on the first power up of the tool, although you are able to go in and alter this at any time.

	<p>Ensure the battery is able to supply a minimum voltage to enable you to operate the tool.</p> <p>Ensure Ignition key is in the position “lock”</p> <p>Connect the Battery Replacement Tool to a vehicle using the 16 Pin Diagnostic plug to any vehicle with a 16 Pin diagnostic socket.</p> <p>Tool display should show the name EXIDE. In any other case verify the connection.</p> <p>The display will present to you the “select language” screen.</p> <ul style="list-style-type: none"> Select the language that you want to use the tool in. <p>The system will register and remember your selection</p>
	<p>The Battery Replacement Tool will then return to the default main screen to allow you to select the vehicle that you wish to operate.</p> <p>If you are coding this vehicle refer to the Replacing the battery section otherwise ensure the ignition is switched off on the vehicle and unplug the tool from the Diagnostic socket.</p>

OPTIONS MENU




Main Menu screen

	<p>This is the Main screen for the tool. From here you can select the vehicle, change the language and view the information screen.</p>
	<p>Select this option to start the Replace Battery process.</p> <p>Select this option to choose and set the different languages.</p> <p>Information screen</p>

REPLACING THE BATTERY



Now you are ready to start using the Battery Replacement Tool to get the new battery validated for the vehicle and cancel battery related faults on the range of cars covered.

Example system:



	<p>First replace the old battery with the new one, ensuring the key is not in the ignition.</p> <p>Connect the Battery Replacement Tool to a vehicle using the 16 Pin Diagnostic plug. The Tool will then power up and show the EXIDE name. In any other case verify the connection.</p> <p>The tool will take you to the Main Menu screen.</p> <p>Using the keypad, navigate to the battery replacement option and press OK.</p>
	<p>Using the keypad to navigate up and down the menus you will be given the following options:</p> <ul style="list-style-type: none"> • Select the Manufacturer. You will then be asked to switch the Ignition On • Select the Function. Select Validate Battery • Follow on screen instructions
	<ul style="list-style-type: none"> • Select the Validate Battery. • Follow on screen instructions <ul style="list-style-type: none"> ○ The system will register a new battery to the vehicle ○ You will be informed if battery validation was concluded successfully.

CHANGING THE PRESET LANGUAGE

If you want to change the language the tool displays you can select this option and choose the correct language you wish to use. This will then be stored in memory until you change it again.

	<p>Using the keypad, navigate to the Language option and press OK.</p>
	<ul style="list-style-type: none"> Select the language that you want to use the tool in. <p>The system will register and remember your selection.</p> <p>The selected Language will now be the default language used.</p>

READING UNIT INFORMATION

 <p>The screenshot shows a black screen with white text. At the top, there are three icons: a battery, a language selection box showing 'FR GB' and 'DE ES', and an information icon. Below these icons, the word 'INFO' is displayed. At the bottom, there is a large white information icon on a black background.</p>	<p>Using the keypad, navigate to the Information option and press OK.</p>
 <p>The screenshot shows a black screen with white text. The top section reads: 'EXIDE BATTERY TOOL (C) 2008-2011 IT IS STRICTLY FORBIDDEN TO DISSEMINATE, DECOMPILE, UNIT INFO'. The bottom section reads: 'REVERSE ENGINEER OR DISASSEMBLE ANY PART OF THE HANDSET HANDSET SERIAL: 18611 PRODUCT TYPE: 15 UNIT INFO'.</p>	<p>The information screen is displayed with a warning along with the Serial number of the unit and the product identification number.</p> <p>You may be asked to navigate to this screen by technical support to establish the serial number of your handset</p>

SOFTWARE UPDATE

Overview:

Software updates are done through an update suite that is available to download from the Exide BRT-12 website. www.spsupport.com/exide

There is also a link directly from the CD that will direct you to the appropriate page on the website.

Download and install the application suite using the application suite user guide for help if required.

Once the suite is installed you simply need to follow the steps shown on screen to update the handset to the latest software.

Minimum requirements:

Windows PC running Windows XP/Vista/7

5MB of free disk space

Free USB port

SPECIFICATIONS

Features:

- High contrast easy to read OLED graphics display.
- PC Updateable via USB and Internet.
- Simple operation using just 6 buttons.
- Powered from the vehicle's 12 Volt J1962 diagnostic socket.
- Handheld design with ruggedised rubber elastomer boot.

Specifications:

- J1850 VPW / PWM
- ISO High & Low Speed
- CAN
- Fault Tolerant CAN

COPYRIGHT AND WARRANTY

Copyright:

BRT-12 tool is made by SP Diagnostics and it is strictly forbidden to disseminate, decompile, reverse engineer or disassemble any part of the hardware or software incorporated within it or associated with it and is protected by international law.

Warranty:

This tool is warranted to be free of defects in materials and workmanship for a period of three years from the date of purchase. Exide and the manufacturer will, at our option, repair the unit or replace the unit with a remanufactured tool. This limited warranty applies only to BRT-12 tool and does not cover any other equipment, static damage, water damage, overvoltage, dropping unit or damage resulting from extraneous causes including owner misuse. Exide and the manufacturer are not liable for any incidental or consequential damages for breach of this warranty. The warranty is void if owner attempts to disassemble the unit or modify the cable assembly.